

Operation Manual for RemoteCom Application Software

Procedure: (Note: You must first connect to the Internet before you can use this Software application)

SERVER

- 1) Click “Connect” to access connection between Client side of this application software.
- 2) Click “Apply” to affirm Port (local) server setup.
- 3) Click Status to confirm connection and a message box will pop-up telling the user that Server is “Listening” or it is in Stand-by mode. When Client has established connection message box will be “Connected”.
- 4) If Client has disconnected Server must “Reset” for connection to be affirmed again.

Note: Once Server and Client have successfully connected Client can automatically or manually send data to Server.

CLIENT

- 1) Click “Connect” to access connection between Server side of this application software.
- 2) Type in the IP address of the Server in the Host (Remote) then click “connect” for connection to push through.
- 3) Click “Status” to confirm connection between the Server.
- 4) Click “Available Com” to view available ports on the Server side.
- 5) Select one of the option box if you want to use single port or dual port in this test software application.
- 6) After doing so Click on “ Setup Serial COM” and setup communication parameters which you want to use.
- 7) Then click “Read Enable” for the transmission of data.
- 8) Type in words on the Transmit text box and you will see the data on the Receive text box.

Note: You must provide a loop back in the Server side in order for you to view the data that you transmitted.